

	<b>WARNING</b> To avoid injury. You <b>MUST</b> read and understand technical manual before servicing this machine.	
--	---	---

# Safety Mat System

## Installation and Operation Manual

Model NSD-DR-01  
Basic DIN-rail Controller



Model NSD-TR-01  
Metal Box Controller



Model NSD-DR-04  
DIN-rail Controller  
(with Diagnostics Message Display)





**DANGER**

**DANGER** indicates a hazardous situation which, if not avoided, will result in death or serious injury.



**WARNING**

**WARNING** indicates a hazardous situation which, if not avoided, could result in death or serious injury.



**CAUTION**

**CAUTION** indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



**NOTICE**

**NOTICE** is used to address practices not related to physical injury.



**SAFETY  
INSTRUCTIONS**

**Safety Instructions** (or equivalent) signs indicate specific safety-related instructions or procedures.

# **NSD Safety Mat System**

Installation and Operation Manual

**Pinnacle Systems, Inc.**  
1510 Hubbard Avenue  
Batavia, IL 60510

P/N: 28-045r2.8

Customer Service: 630-443-8542 (CST)  
(Please have Model #, Serial #, and Software Rev # Available)

Sales and Marketing: 800-569-7697 (EST)

## Proper Use and Limitations

### **⚠️ WARNING**

The NSD Safety Mat System is critical for operator safety. Repairs should only be made by factory authorized personnel. The manufacturer cannot be held responsible for your repair attempts or the unit's subsequent safe operation.

As the NSD Safety Mat System is a single function device, that of sensing an unauthorized intrusion into a guarded area while simultaneously determining that it is capable of sensing such an intrusion, any internal malfunction will manifest itself with a RED condition shut down. The manufacturer will not supply individual component parts of any circuit board but will supply the individual circuit board complete.

The information disclosed herein includes proprietary rights of the manufacturer. Neither this document nor the information disclosed herein shall be reproduced or transferred to other documents, used or disclosed to others for manufacturing purposes, or for any other purposes, except as specifically authorized in writing by the manufacturer. If this manual is supplied in connection with the sale or delivery of manufacturer's equipment, it is to be used solely for maintenance, repair or installation of such equipment.

## Warnings and Warranty

Manufacturer warrants that this product will be free from defects in material and workmanship for a period of two years from the date of shipment thereof. Within the warranty period, manufacturer will repair or replace such products which are returned with shipping charges prepaid and which will be disclosed as defective upon examination by the manufacturer. This warranty will not apply to any product which will have been subject to misuse, negligence, accident, restriction, and use not in accordance with manufacturer's instructions or which will have been altered or repaired by person's other than the authorized agent or employees of the manufacturer.

## Disclaimer

The provisions of the "Warranty" paragraph above are the sole obligations of the manufacturer and exclude all other warranties of merchantability, expressed or implied. Further, there are no warranties which extend beyond the above warranty.

## Limitation of Liability

In the event of any claim for breach of any obligations of manufacturer under any order, whether expressed or implied, and particularly in the event of any claim of a breach of the warranty or warranties contained in the paragraph "Warranty" or of any other warranties, expressed or implied which might, despite the paragraph entitled "Disclaimer," be determined to be incorporated in any order, the company shall under no circumstances be liable for any consequential or special damages, either in law or in equity, or for losses or expenses or claims for the same arising from the use of, or inability to use, the products of the manufacturer for any purpose whatsoever.

The manufacturer has designed this equipment to the very highest performance and safety standards known to the current technological state of the art. However, the installation, usage, suitability, and fitness of our equipment for any purpose, known or unknown, is interdependent upon the performance of other equipment not manufactured, installed, secured or maintained by the manufacturer. We cannot and do not accept responsibility for any overall system performance when factors, such as these, are beyond our control.

### **⚠️ WARNING**

The entire machine safety system must be tested at the start of every shift. Machine testing should include: (1) proper machine operation and stopping capability; and (2) verification of proper installation and settings of all point of operation guards and devices before the operation is released for production.

## Overview

Circuit Description .....	1
---------------------------	---

## Specifications .....

	2
--	---

### Dimensions

1. NSD-TR-01 (Metal Box) Controller .....	3
2. NSD-DR-01 (Basic DIN-rail) and NSD-DR-04 (DIN-rail with diagnostics) Controllers .....	3
3. NSD-TR-01 Mat Controller .....	4

## Installation and Operation

Mat Installation .....	5
------------------------	---

### Controller Installations

NSD-TR-01 (Metal Box) Controller .....	5
NSD-DR-01 (Basic DIN-rail) Controller .....	6
NSD-DR-04 (DIN-rail with diagnostics) Controller .....	6

### Operation

1. Stop Circuit (application) .....	7
2. Manual/Automatic Reset .....	7
3. External Relay Checking .....	7

### Wiring Diagrams

1. NSD-TR-01 (Metal Box) Controller .....	8
1. NSD-TR-01 (Metal Box) Controller - Older boards PRIOR to Rev 10 .....	9
2. NSD-DR-01 (Basic DIN-rail) Controller .....	10
3. NSD-DR-04 (DIN-rail with diagnostics) Controller .....	11

NSD-DR-04 (DIN-rail with Diagnostics) Accessible Connections .....	12
--	----

NSD-DR-04 (DIN-rail with Diagnostics) Board Connector Layout .....	13
--	----

## Appendix A: Safety Guidelines for Management

Operational Safety .....	AA-1
Safety Enforcement .....	AA-2
Supervisor Training .....	AA-2
Operator Training .....	AA-2

## Appendix B: Troubleshooting

NSD-TR-01 (Metal Box) and NSD-DR-01 (Basic DIN-rail) Controllers .....	AB-1
NSD-DR-04 (DIN-rail Controller with diagnostics) .....	AB-1

# Overview

## NSD Safety Mat System

### Overview

The NSD Safety Mat System contains two independent control circuits which allow for shut down due to any single failure in one of the control circuits. The N.O. output circuit is controlled by two captivated contact relays in series which are both monitored. If the contact in one relay should stick closed (i.e., contact weld) the other relay will shut down and an LED will indicate the fault, even if the contact on the bad relay opens back up you must reset the power to clear the fault. The relay contact monitoring provides a high degree of user safety.

### Circuit Description

The NSD-TR-01 (metal box) and NSD-DR-01 (basic DIN-rail) are alike in that they use discrete logic circuits to detect the mat. The NSD-DR-04 (DIN-rail with diagnostics) is diverse redundant microprocessor driven and has a built-in diagnostics display. A low voltage (24VAC) signal is sent out to the safety mat(s) through two wires. The voltage passes through the mat and back into the NSD control unit through two more wires. Two special optically-isolated diverse redundant circuits look at the signals coming back from the mat(s) detecting the presence of proper positive and negative voltage (AC) levels and output their signals to redundant missing pulse detectors. If the voltage coming back is too high or low, the missing pulse detectors will drop out and de-energize the relay circuit. If the voltage coming back is not AC (missing either positive or negative peaks), then the signal going to the missing pulse detector will disappear which will, in turn, drop out and de-energize the relay circuit.

Redundant relay position detectors watch for a relay contact stuck in the wrong position. The circuits will lock out the reset feature of the NSD control unit if a relay contact is closed when it should be open.

Each relay has its own driver circuit to complete the redundancy of the circuits.

The output relays will de-energize if the voltage coming from the mat(s) is either too high or low (12VAC to 36VAC) or is not AC (i.e., DC), including the following reasons:

1. When you step on the mat, you are shorting out the 24VAC signal going back into the NSD control unit to OV, so the relays de-energize.
2. If you cut any wire going to or coming from the mat(s), the signal going back into the NSD control unit is OV, so the relays de-energize.
3. If any wire going to or coming from the mat(s) is cut and/or shorted to any other mat wire, the signal going back into the NSD control unit is OV, so the relays de-energize.
4. If any wire going to or coming from the mat(s) is cut and/or shorted to an outside AC power source (i.e., 120VAC) the signal going back into the NSD control unit will exceed the 24VAC signal level and the relays will de-energize.
5. If any wire going to or coming from the mat(s) is cut and/or shorted to an outside DC power source (i.e., 24VDC), the signal going back into the NSD control unit will not be an AC signal and the relays will de-energize.
6. If, when you step on the mat, either safety output relay is stuck in the closed position, the NSD control unit will automatically shut down the other relay and lock out and further attempts to reset the unit until the power is reset.

# Specifications

## NSD Safety Mat System

	<b>NSD-TR-01 Controller</b> (Metal Box)	<b>NSD-DR-01 Controller</b> (Basic DIN-rail)	<b>NSD-DR-04 Controller</b> (DIN-rail with Diagnostics)
<b>Enclosure:</b>	NEMA 12, 13, IP 54	NEMA 1, IP 32	NEMA 1, IP 32
<b>Input Power:</b>	120VAC +/- 10% @ 3 watts 50-60 Hz fused	24VDC +/- 20% @ 7 watts	24VDC +/- 20% @ 7 watts
<b>Category/Type:</b>	4	4	4
<b>Relay Style:</b>	Monitored force-guided captive contact safety relays	Monitored force-guided captive contact safety relays	Monitored force-guided captive contact safety relays
<b>Relay Configuration:</b>	2 N.O. Safety Relays (closed when circuit activated) 1 Aux Output N.O. or N.C	2 N.O. Safety Relays (closed when circuit activated) 1 Aux Output N.O. or N.C	2 N.O. Safety Relays (closed when circuit activated) 1 Aux Output N.O. or N.C. 1 Fault Relay N.O.
<b>Safety Relay Rating:</b>	4A @ 220VAC	4A @ 220VAC	4A @ 220VAC
<b>Reset Provisions:</b>	Manual or Automatic	Manual or Automatic	Manual or Automatic
<b>Controller Response Time:</b>	15 msec.	15 msec.	19 msec per mat input used
<b>Self-Checking Intervals:</b>	Every 20 msec.	Every 20 msec.	Every 20 msec.
<b>Number of Isolated Zones:</b>	1 to 13 (customer specified)	1 per controller	1 per controller
<b>Maximum Number of Mats:</b>	20	20	4 with homerun wiring 20 with daisy chain wiring
<b>External Reset Provision:</b>	Green push button	Green push button	Green push button
<b>Indicators:</b>			
<i>Internal (on board):</i>	<u>Yellow LED</u> = +5VDC power supply <u>Red LED</u> = Normally dim, brighter when mat is stepped on. Cut wire detected when not lit. <u>Green LED</u> = Relay contact detected closed when it should have been open when not lit. Must reset power to clear.	<u>Green LED(s)</u> = next to each relay (3) <u>Red LED</u> = +12V <u>Yellow LED</u> = +5V <u>Green LED</u> = -5V	<u>Red LED</u> = +12VDC <u>Green LED</u> = +20VDC <u>Yellow LED</u> = +5VDC <u>Green LEDs</u> = one for each relay (4 total)
<i>External:</i>	<u>Red LED</u> = 1 or both relays are de-energized. <u>Green LED</u> = All relays are energized.	<u>Red LED</u> = 1 or both relays are de-energized. <u>Green LED</u> = All relays are energized. <u>Yellow LEDs</u> = 2 to show on/off mat. <u>Yellow LED</u> = relay fault if it turns off.	<u>Red LED</u> = 1 or both relays are de-energized. <u>Green LED</u> = All relays are energized. <u>Yellow LEDs</u> = 1 for each mat status — (4 total)
<b>Diagnostic Message Display:</b>	N/A	N/A	Built-in
<b>Warranty:</b>	2 years	2 years	2 years

# Specifications

## NSD Safety Mat System


### Dimensions

#### NSD-TR-01 (Metal Box Controller)

- Board (NSD-TR-B1): 5" x 7" plate with 4 holes 4-1/4" x 6-1/4" on center.  
127mm x 177.8mm with 4 holes 107.95mm x 158.75mm on center
- Box (NSD-TR-01): 8"h x 6"w x 3.5"d (4" x 8-3/4" holes), NEMA 12, 13  
203.2mm x 152.4mm x 88.9mm (101.6mm x 222.25mm holes)
- (NSD-TR-02): 12"h x 10"w x 5"d (8" x 12-3/4" holes), NEMA 12, 13  
304.8mm x 254mm x 127mm (203.2mm x 323.85mm holes)
- (NSD-TR-03/04): 16"h x 14"w x 6"d (13" x 16-3/4" holes), NEMA 12, 13  
406.4mm x 355.6mm x 152.4mm (330.2mm x 425.45mm holes)
- (NSD-TR-05/up): Call for sizes available.

#### NSD-DR-01 and NSD-DR-04 (both DIN-rail Controller models)


*Mounting:* 35mm DIN-rail mountable or mounting screws on corners of enclosure requiring two combo-head screws (3.5 x 0.6mm x 14mm or #6 x .5).





# Specifications

## NSD Safety Mat System



# Installation and Operation

## NSD Safety Mat System

# SAFETY INSTRUCTIONS

### **WARNING**

The entire machine safety system must be tested at the start of every shift. Machine testing should include: (1) proper machine operation and stopping capability; and (2) verification of proper installation and settings of all point of operation guards and devices before the operation is released for production.

### Mat Installation

The NSD mat system has been designed to promote individual mat "homerun" wiring back to the mat controller. This is suggested for easing installation and diagnostics for maintenance troubleshooting. This will also eliminate cumbersome "daisy chain" wiring practices of mat systems. It also eliminates numerous wiring connection points buried under the perimeter trim which are time intensive to troubleshoot.

- 1) Sweep the floor area where the safety mat is to be installed. The floor should be flat and free of foreign material.
- 2) Locate the safety mat in the desired location. For future reference, install the mat with the label side up.
- 3) Slide the black wire raceway component under the mat edge (Part #M002). Refer to Figure 1 below for proper component positioning.

NOTE: The wire raceway component must be installed whenever the surface perimeter trim component is used.

- 4) Route the wire/plug assembly on the raceway toward the mat controller location.

- 5) Lay the aluminum perimeter trim piece around the mat assembly. Determine where the mat wiring will exit the trim and notch the trim and wire raceway for the wire to exit the assembly.
- 6) If surface metal raceway is used to route the wiring (Part #M005 or M006) from the mat assembly across the floor toward the mat controller, it should be aligned with the notch in the perimeter trim and anchored to the floor. Route wires accordingly and snap cover plate over the wires.
- 7) Slide the perimeter trim over the wire raceway component and align over the mat edge. Drill the perimeter trim and floor for securing the perimeter trim to the floor with anchoring screws and floor anchors.
- 8) If a multiple mat assembly is to be installed, use the aluminum active coupler component (Part #M003) to connect mats end to end or side to side. Refer to Figure 1 below.


### Controller Installation

#### NSD-TR-01 (Metal Box) Controller

### **CAUTION**

The NSD-TR-01 Controller provides both N.O. and N.C. output circuits, but only Terminals 5-6 (N.O.) are safety monitored and should be used in series with your stop circuit. Terminals 7-8-9 are NOT monitored; this output should only be used as an auxiliary signal line.

**Figure 1: Cross Section View of Mat Assembly Active Edging**



## SAFETY INSTRUCTIONS

- 1) Mount the NSD-TR-01 (metal box) where you can get access to it without having to step on the mat.
- 2) Attach 120VAC to Terminals L1 and N2 and Earth ground to GND.
- 3) Wire mat to terminals 1-2-3-4 (1=blue, 2=white, 3=black, 4=brown **for a single 4-wire lead mat** and 1=black, 2=red, 3=red, 4=black **for a two-dual lead mat.**) If your mat has two zip cords (two wires in each cord), then one zip cord goes to Terminals 1-2 and the other to Terminals 3-4 (it does not matter which zip cord).
- 4) Wire Terminals 5-6 into your STOP circuit. Terminals 5-6 come from two N.O. contacts in series for safety (see “important” note above).
- 5) Unit is setup for Manual Reset if you have the Green button on the case.  
*Automatic Reset:* disconnect all four wires from Terminals 14-15-16-17.  
*Remote Manual Reset:* Place one pole of any D.P.N.C. button between Terminals 14-15 and the other pole between Terminals 16-17.
- 6) You can use Terminals 7-8-9 for non-safety indicating or monitoring (i.e., strobe lights, PLC).
- 7) External 24VDC Red Zone light goes to Terminals 11-12; 24VDC Green Zone goes to Terminals 12-13; Terminal 12 is 24VDC out.

### NSD-DR-01 (Basic DIN-rail Controller)

#### CAUTION

You must use both Terminals 7-8 and 9-10 in your Stop circuit. If you have one Stop circuit, you must jumper Terminal 8 to 9, then use Terminal 7 and 10 in your Stop circuit. **Do not use Terminals 11-12-13 for safety circuits.**

- 1) Mount the NSD-DR-01 (basic DIN-rail Controller) inside an enclosure since all the wiring terminates on the outside of the controller box.
- 2) Attach 24VDC to Terminals 1-2 and Earth ground to Terminal on the right side of the DIN-rail controller box.
- 3) Wire mat to Terminals 3-4-5-6 (1=blue, 2=white, 3=black, 4=brown **for a single 4-wire lead mat** and 1=black, 2=red, 3=red, 4=black **for a two-dual lead mat.**)
- 4) Wire your Stop circuit to Terminals 7 and 10. Place jumper between Terminals 8 and 9 (see “important” note above).

## Installation and Operation

### NSD Safety Mat System

- 5) Unit comes setup in manual mode with a jumper between Terminals 2 and 16 (use the built-in “zone reset” button to clear the zone).  
*Automatic Reset:* Remove jumper wire from between Terminals 2 and 16.  
*Remote Reset:* Wire a N.C. push button in place of the jumper wire.
- 6) You can use Terminals 11-12-13 for non-safety indicating or monitoring (i.e., strobe lights, PLC).
- 7) You can install remote red and green lights (Terminals 14-15). These terminals go to GND when active.

### NSD-DR-04 (DIN-rail Controller with diagnostics)

#### CAUTION

You must use both Terminals 4-5 and 6-7 in your Stop circuit. Do not use Terminals 8-9-10-11-12 for safety circuits.

- 1) Mount the NSD-DR-04 (DIN-rail controller with diagnostics) inside an enclosure since all the wiring terminates on the outside of the controller box.
- 2) Select the number of mats (1-4) you want to hook up. Open the DIN-rail box and select the proper jumper settings (see NSD-DR-04 *Jumper Settings, Page 12*).
- 3) Select Automatic or Manual Zone resetting (see *Jumper Settings, Page 12*).
- 4) Select External relay checking (see *Jumper Settings, Page 12*).
- 5) Attach 24VDC to Terminals 1-2 and Earth ground to Terminal 3 of Power/Output connector.
- 6) Wire mat to terminals 1-2-3-4 of each mat connector (1=blue, 2=white, 3=black, 4=brown **for a single 4-wire lead mat** and 1=black, 2=red, 3=red, 4=black **for a single two-dual lead mat.**)
- 7) Wire your Stop circuit to Terminals 4 and 7. Place jumper between 5 and 6 (see “important” note above).
- 8) You can use Terminals 8-9-10-11-12 for non-safety indicating or monitoring (i.e., strobe lights, PLC).
- 9) You can install remote red and green lights (Terminals 7 and 8 of I/O connector). These terminals go to GND when active.

NOTE: Canadian market wiring is black, red, red, black with 18-gauge wiring size.

# Installation and Operation

## NSD Safety Mat System

# SAFETY INSTRUCTIONS

- 10) Remote Zone reset connects to Terminal 3 of I/O connector.
- 11) If you need to use external relays, then connect external relays to Terminals 1-2 of I/O connector (see below for explanation).

### Operation

If you have manual reset (standard), you must push the RESET button to reset the NSD controller.

If you have automatic reset, the NSD Controller will go GREEN when you step off the mat. Automatic reset should not be used in applications where there is no barrier past the mat.

### Stop Circuit (application)

Anyone stepping on the mat(s) will automatically shut the machine off. This circuit allows for multiple numbers of mats to be wired in series to protect a very large area around dangerous equipment with only one NSD Controller.

### Manual/Automatic Reset

*NSD-TR-01 (Metal Box):* If nothing is attached to Terminals 14-15-16-17, then the NSD Controller will automatically reset itself. If you have a pushbutton, simply remove all four of these wires from their terminals.

If a 2 pole N.C. push-button contact is placed across Terminals 14-15 and the second pole is placed across Terminals 16-17, then you must use the push-button to manually reset the NSD Controller unit.

*NSD-DR-01 (Basic DIN-rail):* If you select manual, you will have to go to the control box and press the zone reset button each and every time you step on any mat(s). This requires a jumper wire between Terminals 2 and 16. To remote the zone reset, place a N.C. button in place of the jumper wire.

If you select automatic, the zone will clear itself when you have stepped off the mat(s). Remove the jumper wire from between Terminals 2 and 16.

*NSD-DR-04 (DIN-rail with diagnostics):* If you select manual, you will have to go to the control box and press the zone reset button each and every time you step on any mat(s). Place jumper across JP3 to activate this feature.

To remote the zone reset, place a N.O. button between Terminal 3 of the Input/Outputs connector and Terminal 2 of the Power Connector.

If you select automatic, the zone will clear itself when you have stepped off the mat(s). Remove jumper across JP3 to activate this feature.

### NOTICE

This setting changes all mats. You cannot change some mats to manual and others to automatic.

### External Relay Checking


*NSD-DR-04 (DIN-rail with diagnostics):* This option is selected when you have to switch a large load. This feature allows the NSD to monitor your external relays. This system requires that you use two force-guided relays for the external switching and that the secondary pole of each relay (N.C.) be tied in series back to the NSD control external relay input terminals for each particular zone. Place jumper across JP4 EXT to activate this feature (see Page 10 for wiring diagram).

# SAFETY INSTRUCTIONS

## Installation and Operation NSD Safety Mat System

### Wiring Diagrams

#### NSD-TR-01 (Metal Box Controller)



**NOTICE** If you daisy chain mats, the blue/white is one pair and should go to Terminals #1 and #2. The black/brown is the other and should go to the blue/white pair of the second mat, and so on. The black/brown pair of the last mat goes back to Terminals #3 and #4.

If the mat has two lamp cords, then either pair can go to Terminals #1 and #2 and so on.

Relay Fault LED's D14,D18 (ON=good, OFF=Relay stuck on FAULT)

On Mat LED's D10,D12 (ON=ON mat, OFF=OFF mat)

**NOTICE** Canadian market wiring is black, red, red, black with 18-gauge wiring size.


# Installation and Operation

NSD Safety Mat System

**SAFETY  
INSTRUCTIONS**

## Wiring Diagrams

NSD-TR-01 (Metal Box Controller) - Diagram below is for older boards PRIOR to Rev 10.



### NOTICE

If you daisy chain mats, the blue/white is one pair and should go to Terminals #1 and #2. The black/brown is the other and should go to the blue/white pair of the second mat, and so on. The black/brown pair of the last mat goes back to Terminals #3 and #4.

If the mat has two lamp cords, then either pair can go to Terminals #1 and #2 and so on.


Relay Fault LED's D14,D18  
(ON=good, OFF=Relay stuck on FAULT)

On Mat LED's D10,D12  
(ON=ON mat, OFF=OFF mat)

### NOTICE

Canadian market wiring is black, red, red, black with 18-gauge wiring size.

## NSD-DR-01 (Basic DIN-rail Controller)



### NOTICE

Mat Wiring for Mat Styles "W" and "P" are shown above (Blue, White, Black, Brown)  
 Mat Wiring for Mat Styles "X" and "E" are Black, Red, Red, Black (and are wired in that order)  
 Canadian market wiring is black, red, red, black with 18 gauge wiring size.

### NOTICE

Safety Relay outputs are N.O. (Held Closed) and are wired into your STOP circuit(s).  
 Aux Relay should only be used for indicator lights.

### Manual Relay Latching Reset:

Wire Terminal #2 to #16 and use the Green ZONE RESET button to reset

### Optional Remote Latching Relay Reset:

Use a N.C. push button wired as shown above

### LED indicators:

STOP: Safety Relays OFF (OPEN)  
 RUN: Safety Relays ON (CLOSED)  
 MAT STATUS: OFF = ON Mat  
 Fault When Off: OFF = Relay Fault




# Installation and Operation

NSD Safety Mat System


NSD-DR-04 (DIN-rail Controller with diagnostics)

## SAFETY INSTRUCTIONS

Mat Wiring per Mat Input



External Relay Checking (optional usage)



### NOTICE

Terminal #6 (INPUT/OUTPUT PLUG) is internally connected to Terminal #1 (POWER/OUTPUT) plug. This allows Terminal #6 to provide +24v to the lights for the RSD (Remote Status Display).

### NOTICE

Canadian market wiring is black, red, red, black with 18-gauge wiring size.

#### REMOTE STATUS DISPLAY

- Green: Terminal #8 (INPUT/OUTPUT)
- Red: Terminal #7 (INPUT/OUTPUT)
- Black: Terminal #1 (POWER/OUTPUT)
- White/Black: Terminal #3 (INPUT/OUTPUT) / Terminal #2 (POWER/OUTPUT)
- 12cond cable: J1 (on left side of diagnostics display)



### NSD-DR-04 (DIN-rail Controller with diagnostics)

#### Accessible Connections

J1                      Diagnostics display plug (used by remote status display option)  
 The Plug is located under the top cover on the left side of the controller

**External:**

**POWER/OUTPUT PLUG**

Terminal No.	Usage
1,2,3	+POS, -NEG, EARTH GROUND (24VDC ONLY)
4,5	Safety relay N.O. output (dry contact) (held closed when GREEN)
6,7	Safety relay N.O. output (dry contact) (held closed when GREEN)
8,9,10	Auxiliary relay N.C., COM, N.O.
11,12	Fault relay N.O. (open when faulted)

**INPUT / OUTPUT PLUG**

Terminal No.	Usage
1,2	+pos, -neg External relay checking (option) 24vdc applied across these terminals when external relay is de-energized
3	Remote external zone reset (Ground to reset zone)
4,5	Auxiliary inputs (Ground to activate feature)
6	+24vdc input (Common for terminals 3,4,5) (jumper from term #1 Power/Output)
7	Optional remote RED "STOP" indicator output (Grounded when RED)
8	Optional remote GREEN "RUN" indicator output (Grounded when GREEN)

**MAT 1,2,3,4 INPUT**


Terminal No.	Usage
1,2	20VDC output to mat (1=blue, 2=white) voltage between 1 & 2 alternates (1=black, 2=red for single two-dual lead mats)
3,4	Return from mat (3=black, 4=brown) (3=red, 4=black for single two-dual lead mats)

**NOTICE**

Canadian market wiring is black, red, red, black with 18-gauge wiring size.

### NSD-DR-04 (DIN-rail Controller with diagnostics) Board Connector Layout

J2,J26	MAT INPUT #1 thru #4	JP1,2	NUMBER OF MATS SELECTION
J1	DIAGNOSTICS DISPLAY (remote)	JP3	MANUAL
J120	POWER/OUTPUT	JP4-6	EXT, AUX1, AUX2
D13,14	Safety relay output on (closed)	D3	+12v supply
D16	Auxiliary relay output on	D1	+5v supply
D15	Fault relay output on (closed)	D23	+20v supply



### NSD-DR-04 (DIN-rail Controller with Diagnostics)

#### Jumper Settings

1= jumper install

#### Number of Mats:

##### JP2 JP1

0	0	1 mat
1	0	2 mats
0	1	3 mats
1	1	4 mats

##### JP3

1= Manual relay resetting  
0= Automatic relay resetting

##### JP4

1= External relay checking enabled  
0= Disabled

##### JP5

Not used at this time

##### JP6

Not used at this time

### Safety Guidelines for Management

#### Operational Safety

1. Appoint a Safety Coordinator to be responsible for safety regulations, requirements, and suggestions. He must review and investigate all accidents and "close calls."
2. Establish and issue safety rules. Inform each employee of his responsibilities. Make sure he understands them and knows what is expected of him.
3. A thorough review and an early inspection must be made of existing presses, dies, and point of operation guarding to attain the degree of responsibility required by ANSI B11.1-2009 Safety Standards and Federal State laws. Review what mandatory modifications are necessary.
4. Equipment that is no longer safe and that cannot be economically upgraded should be destroyed.
5. Never allow persons legally under age to operate or assist in the operation of machinery.
6. All personnel must be properly trained to eliminate accidents and injuries.
7. Regardless of the operator's experience, education, or language barrier, it is the responsibility of the supervisor to give him a thorough explanation with each new job assignment.
8. No employee should be given a work assignment that he does not fully understand. Only properly instructed and thoroughly trained personnel should be assigned to work on or with any machine.
9. It shall be the responsibility of the employer to provide an adequate, clean, safe, and uncluttered work area around each machine.
10. If a malfunction is reported, stop the machine immediately, correct the problem, then resume production.
11. Investigate all accidents and close calls. Analyze the reason for occurrence. Take action to prevent recurrence. Keep records of the investigation and preventative steps that were taken.
12. Only employees who understand the machines, operation and safety requirements, and who are able to communicate this knowledge should be given the responsibility of instructing and training others to perform as operators.



#### **CAUTION**

When a mat system is used to protect the operator or passerby from penetration, it must be mounted and properly sized so it is impossible to reach under, around, or over into the hazardous point of operation zone. Safety mat systems normally guard the front or feed area of a machine. The sides of the areas where the safety mat does not guard must be guarded by some other means or by additional safety mats.

If the position of the safety mat(s) will allow the operator or others to place themselves between the sensing field and the hazardous area, auxiliary guards or devices such as safety light curtains, barrier guards or devices should be used in conjunction with the safety mat(s) to prevent the operator or others from exposure to the hazardous area.

If mechanical guards such as: polyurethane, expanded or perforated metal, hairpins, etc., are used to guard these areas, the opening must comply with the OSHA safety distance in relationship to the openings.

After installation of point of operation guards and before a job is released for operation, a check should be made to verify that the guard will prevent the operators hands from reaching into the point of operation or any hazard zone. Always refer to the applicable OSHA & ANSI standard in order to assure proper compliance to the subject machine.

13. Management must decide that personnel protective safety equipment is required to perform each job safely. Items such as safety glasses, shoes, gloves, helmets, hand pads, spats, protective sleeves and material handling equipment are common in the metal working industry. If noise levels are excessive, protective headsets and earmuffs are recommended.
14. When designing point of operation guarding, the manufacturing process should be weighed heavily in favor of operational safety.
15. Establish safe and convenient material handling methods and procedures.
16. Post in convenient areas the names, addresses, and phone numbers of physicians and hospitals, and members of the organization who are to be called in case of emergency.
17. All equipment must be electrically connected according to the National Electric Code and be consistent with other accepted practices.
18. Provide adequate and proper fire protection equipment.

### **Safety Enforcement**

In order to have an effective safety program, management at all levels must enforce every safety rule and regulation. Strong disciplinary measures are sometimes required. They should consist of a warning, written reprimand, work suspension, transfer, demotion, or possibly a dismissal. All infractions must be reported and recorded. Once an infraction is noted, it shows that an unsafe practice or condition has existed. This may be the result of poor planning or improper training and instructing. The reason for the infraction should be analyzed in order to take corrective action.

### **Supervisor Training**

It should be the responsibility of management to instruct their supervisors on safety, giving job instructions, supervising operators, determining accident causes, and building safety attitudes among the machine operators. Accidents can occur due to inadequate training of supervisors.

### **Operator Training**

It shall be the responsibility of management to insure proper training of operators. A specific training program should be instituted to instruct the operator in safety, proper usage of the equipment, and correct operational procedure in performing each and every job. In addition to the supervisor, the operator should be familiar with the proper guarding of the point of operation. Never permit an operator to start a job without complete instructions from his immediate supervisor.



**NSD-TR-01 (Metal Box) and  
NSD-DR-01 (Basic DIN-rail) Controllers**

**PROBLEM:** No indicators are lit

- Cause(s):**
- 1) Incorrect line voltage OR no line voltage.
  - 2) Incorrectly wired.
  - 3) Blown fuse.
  - 4) Bad regulator.

**Cure:** Check fuse, then make sure you have line voltage present at the correct terminals and that its within specifications. If it all checks out, then the control board must be replaced.

**PROBLEM:** NSD control will not go green when reset, relay fault LED is off

- Cause(s):**
- 1) Noise on the power line caused a glitch in the NSD control.
  - 2) Relay contact stayed closed when user stepped on mat.
  - 3) One of the redundant control circuits is faulty.

**Cure:** Remove power to unit for 30 seconds, apply power and hit the RESET button. This should reset the circuits and the NSD control should come back up. Check the relays for signs of contact pitting. Also, it's possible that large voltage spikes on the power line could have caused a glitch in the NSD control and it shut down. If the unit continues have this problem, install MOV's on the power terminals of any nearby motors, or solenoids. These devices cause noise on the power line and the MOV's can usually cure this.

**PROBLEM:** NSD control will not go green when reset, wire fault LED is off

- Cause(s):**
- 1) Wires from mat have not been installed correctly.
  - 2) One or more of the four wires going out to the mat has been cut.

- Cure(s):**
- 1) See wiring diagram page for mat wire colors and terminals.
  - 2) Repair or replace cut wires.

**PROBLEM:** NSD control will not go green when reset, all internal indicators are on

- Cause(s):**
- 1) Object on mat is keeping control RED.
  - 2) Short in either the mat or external wires going to the mat.
  - 3) You forgot to press the RESET button to reset the mat.

**Cure:** Remove the mat wires from the control unit and use an OHM meter to check for a short between the wires or between each pair of wires on the mat. If there is a short, check for physical signs of damage to the wiring or the mat. The mat will require replacement if the short is not in the wiring.

**NSD-DR-04  
(DIN-rail Controller with diagnostics)**

**PROBLEM:** Mat wiring fault

- Cause(s):**
- 1) Low voltage on input that should be ground.
  - 2) High voltage on input that should be ground.

**Cure:** Bad wiring, bad comparator, or bad mat.

**PROBLEM:** Circuit fault

- Cause(s):**
- 1) Voltage to mat below low setpoint.
  - 2) Voltage to mat below high setpoint.
  - 3) One of the redundant circuits indicates ON mat, the other indicates OFF mat.
  - 4) One of the redundant circuits indicates OFF mat, the other indicates ON mat.
  - 5) High voltage on input that should be ground.

**Cure:** Bad wiring, bad comparator, or bad mat.

**PROBLEM:** Zone # out of sequence

**Cause:** The master and slave processors disagree on which sequence they are on.

**Cure:** An external electrical noise could be causing one of the processors to loose sequence.

# Appendix "B"

## Troubleshooting

**PROBLEM: Zone 1 relay off, should be on**

**Cause(s):** Relay found in the wrong state; circuitry failure or relay failure.

**Cure:** Call for assistance.

**PROBLEM: External relay contact welded/cut**

**Cause:** External relay check input remained open (0 volts) while the zone was de-energized.

**Cure:** When the zone is de-energized (RED), your external relay must close within 1/4 second.

**PROBLEM: External relay contact short**

**Cause:** External relay check input remained closed (voltage applied) while the zone was energized.

**Cure:** When the zone is energized, the secondary pole of your external relay (N.C.) must open up within 1/4 second.

**PROBLEM: Mat # out of sequence**

**Cause:** The master and slave processors disagree on which sequence they are on.

**Cure:** Could have an electrical noise problem causing one of the processors to loose sequence.

**PROBLEM: Ram failure**

**Cause:** Microprocessor failed the internal memory test.

**Cure:** Call for assistance.

**PROBLEM: Power failure**

**Cause:** Circuitry failure; brown out.

**Cure:** Call for assistance.

**PROBLEM: Watchdog failure**

**Cause:** Watchdog circuitry failure.

**Cure:** Call for assistance.

**PROBLEM: Serial data corrupted**

**Cause:** Electrical noise getting into the control box causing one of the computer to reset.

**Cure:** Place MOV's across the coil of any device (outside this control) switched on/off by the relay outputs of this controller.

**PROBLEM: Serial data transmission incomplete**

**Cause:** Electrical noise getting into the control box causing one of the computer to reset.

**Cure:** Place MOV's across the coil of any device (outside this control) switched on/off by the relay outputs of this controller.

**PROBLEM: Master relay on, Slave relay off**

**Cause(s):** The master processor disagrees with the slave.

**Cure:** Call for assistance.

**PROBLEM: Slave relay on, Master relay off**

**Cause:** The slave processor disagrees with the master.

**Cure:** Call for assistance.










# Total Safety Solutions

Made in USA



## Control Reliable Machine Guarding Safety Devices and Controls for Industry

- Safety Light Curtains (all types and styles)
- Safety Mat Systems (all types and styles)
- Universal Safety Controller HUB / Safety PLC
- Ergonomic Palm Buttons *UltraTouch*
- Safety Interlock Switches (including explosion proof)
- Fencing with Interlocks
- Stack Lights and E-Stops
- OSHA and ANSI Compliant Controls
- Customized "control reliable" controls for dual solenoid activated pneumatic & hydraulic applications
- Energy Isolation and Single Point Lockout Systems
- Plant Surveys and Risk Assessment
- Stainless Steel Enclosures Available
- Customized Control Panels

(800) 569-7697

[sales@pinnaclesystems.com](mailto:sales@pinnaclesystems.com)

[www.pinnaclesystems.com](http://www.pinnaclesystems.com)



## OSHA/ANSI Compliant Clutch/Brake Punch Press Controls and Press Automation Control Systems for the Metal Stamping/Forming Industries

- Punch Press Clutch / Brake Controls
- Resolver Based Clutch / Brake Controls
- Rotary Cam Based Clutch / Brake Controls
- Punch Press Automation Controls
- Time Based Brake Monitors
- Die Protection Systems
- OSHA and ANSI Compliant Controls
- Programmable Limit Switches
- Tonnage Monitoring
- Servo Feed Interface
- Customized Punch Press Controls
- Press Brake Guarding for Mechanical, Air Clutch and Hydraulic Press Brakes
- Stainless Steel Enclosures Available

(800) 937-4334

[sales@pressroomelectronics.com](mailto:sales@pressroomelectronics.com)

[www.pressroomelectronics.com](http://www.pressroomelectronics.com)

# The Ultimate in Safety - Quality - Value

### **WARRANTY**

Manufacturer warrants that this product will be free from defects in material and workmanship for a period of one year from the date of shipment thereof. Within the warranty period, manufacturer will repair or replace such products which are returned to it with shipping charges prepaid and which will be disclosed as defective upon examination by the manufacturer. This warranty will not apply to any product which will have been subject to misuse, negligence, accident, restriction, and use not in accordance with manufacturer's instructions or which will have been altered or repaired by persons other than the authorized agent or employees of the manufacturer.

### **DISCLAIMER**

The provisions of the paragraph "Warranty" are the sole obligations of the manufacturer and exclude all other warranties of merchantability, expressed or implied. Further, there are no warranties which extend beyond the above warranty.

### **DISCLAIMER**

Pinnacle Systems, Inc. does not assume liability for the contents of this publication or the use of any products described. Pinnacle Systems, Inc. reserves the right to make changes to the products or any catalogs without further notice.

### **ERRORS AND OMISSIONS**

Information presented by Pinnacle Systems, Inc. has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

### **LIMITATION OF LIABILITY**

In the event of any claim or breach of any obligations of manufacturer under any order, whether expressed or implied, and particularly in the event of any claim or a breach of the warranty or warranties contained in the paragraph "Warranty" or of any other warranties, expressed or implied which might, despite the paragraph entitled "Disclaimer," be determined to be incorporated in any order, the company shall under no circumstances be liable for any consequential or special damages, either in law or in equity, or for losses or expenses or claims for the same arising from the use of, or inability to use, the products of the manufacturer for any purpose whatsoever.

### **⚠️ WARNING**

The entire machine safety system must be tested at the start of every shift. Machine testing should include: (1) proper machine operation and stopping capability; and (2) verification of proper installation and settings of all point of operation guards and devices before the operation is released for production.

### **CHANGE IN SPECIFICATIONS**

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be reassigned to fix or establish key specifications for your application. Please consult the factory.



# PINNACLE

S Y S T E M S , I N C .

## Sales and Marketing Offices

### United States

Pinnacle Systems, Inc.  
P.O. Box 100088  
Pittsburgh, PA 15233  
Toll Free Number: 800-569-7697  
Direct Number: 412-262-3950  
Fax: 412-262-4055

### Service and Manufacturing

Pinnacle Systems, Inc.  
1510 Hubbard Avenue  
Batavia, IL 60510  
Direct Number: 630-443-8542  
Fax: 630-443-8601

## Customer Service: (630) 443-8542

We have designed our equipment to the very highest performance and safety standards known to the current technological state of the art, as evidenced by our U.S.A. and foreign patents issued and pending. However, the installation, usage, suitability, and fitness of our equipment for any purpose, known or unknown, is interdependent upon the performance of other equipment not manufactured, installed, secured or maintained by Pinnacle Systems, Inc.

We cannot and do not accept responsibility for any overall system performance when factors, such as these, are beyond our control.

[www.pinnaclesystems.com](http://www.pinnaclesystems.com)

[sales@pinnaclesystems.com](mailto:sales@pinnaclesystems.com)  
[service@pinnaclesystems.com](mailto:service@pinnaclesystems.com)